

Quick Vault XL Installation Guide

Notes:

Best Location

1. Choose a wall that does not have wiring or plumbing behind the drywall.
2. Use a stud finder to locate the edges of the 2x4's.
3. The distance between the 2 inner edges of the 2x4's should be approximately 14".
4. Position the cutout at a desired height. The hole size to cut in the wall should be 28 1/4" tall x 14" wide.
5. Use a drywall saw to cut out the drywall. Remove the cutout portion of the drywall from the wall.

Installation:

1. Install the interior shelves (3) to the desired height and secure with the supplied sheet metal screws (6). Note: the notched shelf fits in the center 1/3 section of the QVXL and the 2 full shelves fit in the upper and bottom 1/3 of the QVXL.
 2. After the install hole has been cut and all the excess drywall removed, insert the Quick Vault XL into the cavity.
 3. Open the door and drill 6 pilot holes into the 2x4's using the 6 predrilled holes as a guide on inside sides of the Quick Vault XL using a 7/32" drill bit to accommodate the 6 supplied 1/4" lag bolts.
 4. Secure the Quick Vault XL by screwing in the lag bolts with a socket and a ratchet.
 5. See instructions to reset your personal code.
4. The Quick Vault XL is now in place and should be flush and straight in the wall. For additional concealment hang a picture or mirror over the Quick Vault XL.

