



**CONSOLE VAULT®**  
INNOVATIVE SECURITY SOLUTIONS

(800) 878-1369

www.consolevault.com

## 2019 + — Honda Pilot/ Ridgeline/ Passport

### Instruction Sheet (1107)



#### Installation Steps:

- 1) If applicable, reset the combination lock before beginning installation.
- 2) Remove all contents from the center console, and unsnap the **Sliding Tray** by firmly pulling up. (1)
- 3) Remove the **OE Rubber Pad** and both **OE Screws** from the bottom of the Console.
- 4) Notice the rail outlined red in image (2). If this rail is not flush with the surrounding console wall press it firmly into the console so that it does not protrude and interfere with installation. (2)
- 5) Insert the **Hinged Frame** with the rectangular shaped hole positioned towards the front of the vehicle. (3)
- 6) Position the **Tray Sliders** all the way towards the front of the Console, and insert the **Top Frame** by maneuvering around the **Tray Sliders**. (4)
- 7) With the **Top Frame Door** in the open position, simultaneously pull the **Top Frame** up and rotate the **Front** and **Rear Hinge Plates** open to ensure slotted holes engage with the **Pre-Mounted Screws**. (5) & (6)
- 8) Assemble all **4 nuts** using a **1/2 Socket Wrench**. (7)
- 9) First remove the **Rubber Dust Cap** from the **USB Cable**, then assemble to the **Top Frame** using a **#1 Phillips Screw Drive**. **NOTE: Do not over tighten screws, as this may damage the USB Cable mounting feature.** (8)
- 10) Plug the **USB Cable** into the Console's USB Port. (9)
- 11) Insert the two provided **Allen Head Screws** and tighten using a **5/32" Allen Wrench**. (10)

