

## 2022+ Jeep Grand Cherokee / 2021+ Jeep Grand Cherokee L Instruction Sheet (1129)

Hidden Hinge Design (U.S. Patent Pending)

Installation Steps:

- 1) Review all steps before initiating installation.
- 2) If applicable, reset the combination lock before beginning installation.
- 3) Remove all contents from the center console.
- 4) For install, the safe should be oriented such that the lock is towards the rear of the vehicle. Carefully slide in the safe body into the console (**Image 4-A**); you may do this with the safe door open if needed. Be sure that the vault is seated all the way down into the console compartment. (**Image 4-B**)
- 5) Hand start the (3X) self-drilling screws (**Image 5**), 2X at the back of the safe and 1X at the front of the safe, then tighten with a **7/16**" **socket wrench** until they come to a hard stop. <u>*Warning! Overtightening screws will cause damage to threads.*</u>
- 6) Place the provided mat inside the safe.
- 7) The installation is now complete!







