



CONSOLE VAULT®

INNOVATIVE SECURITY SOLUTIONS

(800) 878-1369 www.consolevault.com

**2021+ — Chevy Tahoe,
Suburban/GMC Yukon, Yukon XL
Instruction Sheet (1120)**



Installation Steps:

- 1) If applicable, reset the combination lock before beginning installation.
- 2) Remove all contents from the center console and open the door on the Console Vault safe.
- 3) Using a 10mm socket wrench, unfasten the two (2) OEM screws from the bottom of the inside of the console. Set aside for later. **(1)**
- 4) Remove the pad from inside the safe. Set aside for later.
- 5) Using two hands, gently slide the safe into the console. **(2)**
- 6) Insert the two (2) OEM screws through the mounting holes in the bottom of the safe. Hand start the screws, then use a 10mm socket wrench to fully tighten. **(3)**
- 7) Place the pad inside the safe. **(4)**
- 8) The installation is now complete!

