

# LOCK'ER<sup>®</sup> DOWN

## INSTALLATION INSTRUCTIONS

### LD3026

[Model 2015-2022 Ford F150 and 2017-2022 Ford Super Duty Crew Cab Under Seat Long Gun Safe]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Lift up both rear seats of your vehicles.
3. Remove the neoprene padding or convoluted foam from the inside of the safe for now.
4. On the passenger side rear seat, there are two brackets holding the seat to the vehicle, one of the brackets is next to the door, and the other bracket is in the middle of the cabin (slightly right of middle)
  - a. Remove the bolts holding the seat brackets to the vehicle and retain, they will be used for attaching the safe brackets to the seat bracket. **DO NOT USE POWER TOOLS!**
  - b. If your vehicle has a plastic bracket below the seat bottom on the left side rear, **REMOVE AND REPLACE WITH THE LOCK'ER DOWN PROVIDED BLACK METAL BRACKET INCLUDED WITH THE SAFE!**
5. Place each of the **LOCK'ER DOWN** provided **BRACKETS** on the seat bracket, where the stud is facing forward, and the hole on the bottom bracket fits over the bolt hole for the seat bracket.
  - a. Install the seat bracket bolts removed in **Step 4.a**, then attach the cover bracket by making sure the tabs slot into the bottom bracket.
6. Insert the safe over the studs from the installed brackets, and secure the safe to the vehicle using the **LOCK'ER DOWN** provided nuts.
  - a. These nuts are applied inside the safe over the studs on the brackets.
7. Tighten the nuts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE VEHICLE OR SAFE.**
8. Re-insert the padding or foam that was removed from the safe before installation.
9. Enjoy your purchase!

### Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 13mm Socket bit and 14mm bit

**Contents Included:** 2 13mm Nuts

